

Software Requirements Specification

(Pflichtenheft)

(TINF19C, SWE I Praxisprojekt 2020/2021)

Project: **Modelling Wizard**

Customer: Rentschler
 Rotebühlplatz 41
 70178 Stuttgart

Supplier: by Timo Zaoral - Team 2
 (Stefan Banov, Phillip Tran, Simon Jess, Tobias Roth, Jakob Schmidt, Timo Zaoral)
 Rotebühlplatz 41
 70178 Stuttgart

Version	Date	Author	Comment
0.1	21.10.2020	Timo Zaoral	Created
0.2	23.10.2020	Markus Rentschler	Gereviewt: Das SRS sollte in Englisch verfasst und im GitHub-Wiki untergebracht werden!
0.3	26.10.2020	Timo Zaoral	Sprache Englisch, neue Einträge und Bugs ersetzt durch Issue Links
0.4	31.10.2020	Timo Zaoral	Use Cases hinzugefügt
0.5	06.11.2020	Timo Zaoral	Änderungen nach Review

CONTENTS

1. Goal.....	4
2. Use Cases.....	5
2.1. <UC.001> "Create device manually".....	5
2.2. <UC.002> "Create Device by import of IODD or GSD".....	6
2.3. <UC.003> "Create interface or load interface from Library".....	6
2.4. <UC.004> "View device data and device interface data".....	6
2.5. <UC.005> "Reloading and editing an AML device description".....	7
2.6. <UC.006> "Add Attachments for the Device".....	8
2.7. <UC.007> "Format output as CAEX version 2.15 or 3.0".....	8
3. Non-functional Requirements.....	9
3.1. /NF10/ Overview.....	9
3.2. /NF20/ Load Attributes.....	10
3.3. /NF30/ Application Load Toolbar.....	10
3.4. /NF40/Application Load Window Sizing.....	11
3.5. /NF50/Rename Documents.....	11
3.6. /NF60/Resizable Rows.....	11
3.7. /NF70/Header Overview.....	12
3.8. /NF80/Design of the Button's.....	12
3.9. /NF90/Design of the Tab's.....	13
3.10. /NF100/Testability of AML device.....	13
4. Functional Requirements.....	14
4.1. /F10/ Link to Manual.....	14
4.2. /F20/ Add Button at Interfaces.....	14
4.3. /F30/Mechanical and Hydraulic Interfaces.....	14
4.4. /F40/CAEX 2.15 Output.....	15
4.5. /F50/CAEX 3.0 Output.....	15
4.6. /F60/Parameter Requirements.....	16
4.7. /F70/Delete Empty Fields.....	16
4.8. /F80/Delete Button.....	17
5. Bug Fixes	18
5.1. /BUG10/Generic Information Exception.....	18

5.2.	/BUG20/Electrical Interfaces Exception.....	18
5.3.	/BUG30/Generic Information Table Exception	18
6.	Figures	19
7.	References	20


1. Goal

The Goal of this project [1] is to improve the existing software. The software is to be tested for quality defects applying the typical use cases, paying attention to the usability and the "Look&Feel" of the user interface. Based on this, a usability concept will be developed and implemented.

Another point is the support of additional model interfaces and the possibility to use AML interface libraries.

For the file extraction it should be possible to choose between the versions 2.15 and 3.0 of the CAEX output format.

2. Use Cases



2.1. <UC.001> "Create device manually"

Use Case's Objective:	<i>Creating a device by inserting the data manually into the user interface.</i>
System Boundary:	<i>Modelling Wizard for Devices Plugin</i>
Precondition:	<i>The user needs to have the specific data for the device.</i>
Postcondition on success:	<i>the relevant data is displayed completely and correctly</i>
Involved Users:	<i>Each user of the AutomationML-Editor-Application with the Modelling Wizard for Devices Plugin.</i>
Triggering Event:	<i>When the user has the need to add a device.</i>

2.2. <UC.002> "Create Device by import of IODD or GSD"

Use Case's Objective:	<i>Creating a device by importing an IODD file or a GSD file.</i>
System Boundary:	<i>Modelling Wizard for Devices Plugin</i>
Precondition:	<i>The user needs to have the specific IODD or GSD file for the device.</i>
Postcondition on success:	<i>The file was successfully processed, and the relevant data extracted.</i>
Involved Users:	<i>Each user of the AutomationML-Editor-Application with the Modelling Wizard for Devices Plugin.</i>
Triggering Event:	<i>When the user has the need to add a device.</i>

2.3. <UC.003> "Create interface or load interface from Library"

Use Case's Objective:	<i>Creating a device interface by inserting the data manually into the user interface. Or to add an interface from one of the existing libraries.</i>
System Boundary:	<i>Modelling Wizard for Devices Plugin</i>
Precondition:	<i>The user needs to have the specific data for the device.</i>
Postcondition on success:	<i>The user has submitted the specific data completely and correctly.</i>
Involved Users:	<i>Each user of the AutomationML-Editor-Application with the Modelling Wizard for Devices Plugin.</i>
Triggering Event:	<i>When the user has the need to add a device interface.</i>

2.4. <UC.004> "View device data and device interface data"

Use Case's Objective:	<i>After at least one device was successfully added, the device data should be visible and editable on the user interface.</i>
System Boundary:	<i>Modelling Wizard for Devices Plugin</i>
Precondition:	<i>The user added a device.</i>
Postcondition on success:	<i>The user added at least one device successfully.</i>
Involved Users:	<i>Each user of the AutomationML-Editor-Application with the Modelling Wizard for Devices Plugin.</i>
Triggering Event:	<i>When the user has the need to view device data and device interface data.</i>

2.5. <UC.005> "Reloading and editing an AML device description"

Use Cases Objective:	<i>Reloading a device to display and edit the device data on the user interface.</i>
System Boundary:	<i>Modelling Wizard for Devices Plugin</i>
Precondition:	<i>There is an AMLX-package to reload.</i>
Postcondition on success:	<i>The AMLX-package is correct and complete and not damaged in any way.</i>
Involved Users:	<i>Each user of the AutomationML-Editor-Application with the Modelling Wizard for Devices Plugin.</i>
Triggering Event:	<i>When the user has the need to edit an AML device description.</i>

2.6. <UC.006> "Add Attachments for the Device"

Use Cases Objective:	<i>It is possible to add an Attachment to the object, such as a Manufacture Icon.</i>
System Boundary:	<i>Modelling Wizard for Devices Plugin</i>
Precondition:	<i>The user has loaded or added a device.</i>
Postcondition on success:	<i>The user has loaded or added at least one device successfully.</i>
Involved Users:	<i>Each user of the AutomationML-Editor-Application with the Modelling Wizard for Devices Plugin.</i>
Triggering Event:	<i>When the user has the need to add an Attachment on the Device.</i>

2.7. <UC.007> "Format output as CAEX version 2.15 or 3.0"

Use Cases Objective:	<i>It is possible to output the file in CAEX 2.15 or 3.0.</i>
System Boundary:	<i>Modelling Wizard for Devices Plugin</i>
Precondition:	<i>The user has loaded or added a device.</i>
Postcondition on success:	<i>The user has loaded or added at least one device successfully.</i>
Involved Users:	<i>Each user of the AutomationML-Editor-Application with the Modelling Wizard for Devices Plugin.</i>
Triggering Event:	<i>When the user has the need to output the file in a newer or older version of CAEX.</i>

3. Non-functional Requirements

3.1. /NF10/ Overview

The entire space should be used to display the work area more clearly.

The screenshot shows a software interface for 'Generic Data' with tabs for 'Documents' and 'Interfaces'. The 'Generic Information' section contains a table with columns 'Index', 'Role', and 'Add to AML-File'. The table has two rows: one with index '1' and role 'AutomationComponent(Class: AutomationMLBaseRole)', and another with index '*' and role '*'. Below this is a large grey rectangular area. The 'Attributes' section has a 'Header' tab with a table with columns 'AttributeName', 'Values', 'Default', 'Units', 'DataType', and 'Semantic'. This table has one row with index '*'. Below this is another large grey rectangular area. Two large red 'X' marks are overlaid on the interface: one on the right side covering the 'Generic Information' table and the 'Attributes' table, and another at the bottom covering the two large grey rectangular areas. This indicates that these areas should be used to display the work area more clearly.

Index	Role	Add to AML-File
1	AutomationComponent(Class: AutomationMLBaseRole)	<input type="checkbox"/>
*	*	<input type="checkbox"/>


AttributeName	Values	Default	Units	DataType	Semantic
*					

Figure 1 NF10

As shown in Figure 1, the area highlighted with a red cross should also be used.

3.2. /NF20/ Load Attributes

When a file is loaded the attributes of the element should be displayed directly.



	AttributeName	Values	Default	Units	DataType	Semantic
*						

Figure 2 NF20

As you can see in Figure 2, when you load a file, the attributes are not displayed directly and you would have to press 2 clicks to display them.

3.3. /NF30/ Application Load Toolbar

When you open the application for the first time, the right toolbar should not be on the right side as shown in Figure 3. It should be directly visible in the interface.




Figure 3 NF30

3.4. /NF40/Application Load Window Sizing

When you start the application for the first time, it will be displayed very small, see Figure 4, but it should be displayed in full screen mode.




Figure 4 NF40

3.5. /NF50/Rename Documents

The tab Documents from Figure 5 should be renamed to Attachments for better understanding.



Figure 5 NF50

3.6. /NF60/Resizable Rows


The size of the fields can be adjusted in height, which is unnecessary because line breaks are not possible.

	AttributeName	Values	Default	Units	DataType
	IdentificationData				
	Manufacturer	saf			xs:string
	ManufacturerURI	test test test test test tset			xs:string
	DeviceClass				xs:string
	Model				xs:string
	ProductCode				xs:string
	OrderCode				xs:string

Figure 6 NF60

3.7. /NF70/Header Overview

An unnecessary grey field is displayed in the Header tab. This should be removed.



The screenshot shows a software interface with two tabs: 'Attributes' and 'Header'. The 'Header' tab is active, displaying a table with the following fields:

Copyright	
Referenced Class Name	
Referenced Base Class Path	
Attribute Path	
ID	445448458452469
Name	Mustermann

Figure 7 NF70

3.8. /NF80/Design of the Button's

In general, buttons are very difficult to recognize as such and do not have a uniform style.




Figure 8 NF80

3.9. /NF90/Design of the Tab's

As shown in Figure 9, tabs are displayed differently and are not delimited by edges. This should be made uniform.




Figure 9 NF90

3.10. /NF100/Testability of AML device

A created AML device should be validated by the AML Component Checker.[5]

4. Functional Requirements

4.1. /F10/ Link to Manual

The link under help/manual must be placed on a page that can be reached.




Figure 10 F10

4.2. /F20/ Add Button at Interfaces

The Add button, as in Figure 11 for the interface view, is not necessary. Interfaces should always be added to the AML file by default.




Figure 11 F20

4.3. /F30/Mechanical and Hydraulic Interfaces

For the interfaces, not only electrical interfaces, but also the other connectors and interfaces of AutomationMLComponentStandardRCL and AutomationML-ComponentBaseICL should be available, e.g. mechanical and hydraulic interfaces.




Figure 12 F30_1




Figure 13 F30_2

4.4. /F40/CAEX 2.15 Output

The selection of CAEX 2.15 as output format should be implemented.

4.5. /F50/CAEX 3.0 Output

The selection of CAEX 3.0 as output format should be implemented.

4.6. /F60/Parameter Requirements

As shown in Figure 14, other mandatory attributes should be highlighted in red. These are those required by the minimum rules for AML-DDs.

The following attributes are mandatory:

Manufacturer

ManufacturerURI

Model

AttributeName	Values	Default	Units	DataType	Semantic
IdentificationD...					
Manufacturer				xs:string	
ManufacturerURI				xs:string	
DeviceClass				xs:string	
Model				xs:string	
ProductCode				xs:string	
OrderCode				xs:string	
HardwareRevisi...				xs:string	
SoftwareRevision				xs:string	
SerialNumber				xs:string	
FabricationNum...				xs:string	

Figure 14 F50

4.7. /F70/Delete Empty Fields

Newly added empty fields remain even though they are empty and can be collected. This should be prevented.

Index	Role	Add to AML-File
1	AutomationComponent{Class: AutomationMLBaseRole}	<input checked="" type="checkbox"/>
		<input checked="" type="checkbox"/>
		<input type="checkbox"/>
		<input type="checkbox"/>
		<input type="checkbox"/>
		<input type="checkbox"/>
		<input type="checkbox"/>

Figure 15 F60

4.8. /F80/Delete Button

The "Delete" button under Generic Data and Interfaces is currently not working. The function to remove elements should be implemented.

Generic Data | Documents | Interfaces

Generic Information Delete

	Index	Role	Add to AML-File
			<input checked="" type="checkbox"/>
		test	<input type="checkbox"/>
			<input type="checkbox"/>
*			<input type="checkbox"/>

(1)(1)AutomationMLComponentStandardRCL/AutomationComponent

Attributes | Header

	AttributeName	Values	Default	Units	DataType
▶					
*					

Figure 16 F70

5. Bug Fixes

5.1. **/BUG10/Generic Information Exception**

See the issue tracker in the GitHub project at this link. [2]

5.2. **/BUG20/Electrical Interfaces Exception**

See the issue tracker in the GitHub project at this link. [3]

5.3. **/BUG30/Generic Information Table Exception**

See the issue tracker in the GitHub project at this link. [4]

6. Figures

Figure 1 NF10	9
Figure 2 NF20	10
Figure 3 NF30	10
Figure 4 NF40	11
Figure 5 NF50	11
Figure 6 NF60	11
Figure 7 NF70	12
Figure 8 NF80	12
Figure 9 NF90	13
Figure 10 F10	14
Figure 11 F20	14
Figure 12 F30_1	14
Figure 13 F30_2	15
Figure 14 F50	16
Figure 15 F60	16
Figure 16 F70	17

7. References

- [1] <https://github.com/Rajkumarpulaparthi/ModellingWizard>
- [2] <https://github.com/DekaAthlos/TINF19C-ModellingWizard/issues/5>
- [3] <https://github.com/DekaAthlos/TINF19C-ModellingWizard/issues/6>
- [4] <https://github.com/DekaAthlos/TINF19C-ModellingWizard/issues/7>
- [5] <https://amlcc.tarakos.de/Identity/Account/Login?ReturnUrl=%2F>